

INSTRUCTIONS FOR A CORRECT APPLICATION

The Oikogrip® sticker provides protection against abrasions and scratches on indoor & outdoor sports floors, ensuring maximum non-slip stability for athletes. Designed and created by Oikogrip, this non-slip sticker is the result of over 20 years of consolidated experience managing national and international basketball events, primarily as a FIBA Event Provider.

Important Preparation: Prior to installation, ensure that the court has been **thoroughly cleaned** and is completely free of dust and grease. For optimal adhesion, clean the application surface with pure alcohol and wait for the floor to dry completely.

Required Tools: To install the Oikogrip® sticker correctly, you will need a tape measure, a cutter, a squeegee, and masking tape.

INSTALLATION STEPS:



Position: Temporarily fix the sticker in the desired position. Use masking tape to secure it in place if needed.



Start Peeling: Peel off the first section of the backing (approx. 15 cm / 6 inches), fold the backing underneath, and firmly press the exposed adhesive part onto the floor.



Apply and Smooth: Slowly continue removing the backing while simultaneously pressing the sticker down using the squeegee. Firmly press down along the edges to prevent bubbles or wrinkles from forming.



Multi-Part Stickers: If your sticker consists of several parts, we recommend applying the center piece first. Then, lay out the side pieces, ensuring they perfectly align with the exact shape of the logo. In some cases, a 1 cm overlap is recommended.

INFO: +39 085 813 1798 - info@oikogrip.com
Oikogrip® anti-slip product package

INSTRUCTIONS FOR A CORRECT APPLICATION

The Oikogrip® sticker provides protection against abrasions and scratches on indoor & outdoor sports floors, ensuring maximum non-slip stability for athletes. Designed and created by Oikogrip, this non-slip sticker is the result of over 20 years of consolidated experience managing national and international basketball events, primarily as a FIBA Event Provider.



Important Preparation: Prior to installation, ensure that the court has been **thoroughly cleaned** and is completely free of dust and grease. For optimal adhesion, clean the application surface with pure alcohol and wait for the floor to dry completely.

Required Tools: To install the Oikogrip® sticker correctly, you will need a tape measure, a cutter, a squeegee, and masking tape.

INSTALLATION STEPS:



Start by establishing a baseline measurement to ensure the graphic is straight and properly aligned. Once the graphic is where you want it, place a piece of masking tape vertically down the center to act as a "hinge." Put an extra piece of tape on one side to prevent the decal from shifting.



Apply the first Half: Fold back one side of the graphic, peel off the backing paper up to the tape hinge, and tear or carefully cut the excess backing paper away.

Squeegee: Using a squeegee, credit card, or similar flat tool, slowly press the vinyl onto the surface. Use a back-and-forth motion, taking small "bites" of about 1/2 to 3/4 of an inch at a time to prevent air bubbles from getting trapped.

Apply the Second Half: Remove the tape hinge entirely. Then, flip the other unapplied side of the graphic over, remove the remaining backing paper, and press the vinyl onto the substrate using the same slow, back-and-forth squeegee technique.



Remove the Transfer Tape: Go over the entire graphic one last time with the squeegee to ensure there are no bubbles.

Finally, remove the top transfer tape by pulling it back sharply against itself (flat against the surface), rather than pulling it straight up, to reveal your finished sign.



Please avoid foot traffic on the newly applied decal and allow 24 hours for the adhesive to fully cure.